Hi-Performance MARINER OUTBOARDS





MERCURY PERFORMANCE OUTBOARDS

service bulletin

No. 92-6

MHP 2.5 LITRE ECU TEST P/N 11350A17

NOTE: **Refer to EFI manual 90-13833-3 for tester set-up**

		SWITCH POSITION  ECU PARAMETERS	**SWITCH POSITION**  SYSTEM PARAMETERS	**NORMALIZING** the EFI system  ECU NORMALIZE	1. Set ECU Parameters switch to position 1. 2. Set System Parameters switch to position A. 3. Rotate ECU Normalize knob to to obtain reading of 1.50 on meter. ECU is now normalized. **DO NOT** move ECU Normalize knob once reading is obtained. 4. If 1.50 is not attained, ECU is faulty.
	Test Steps	**ECU Parameters Switch Positions**	**System Parameters Switch Position**	**Specified Reading**	**CORRECTIVE ACTION if readings do not match**
ECU TEST	1	2	A	1.14 ± .04	Faulty ECU
	2	3	A	.84 ± .04	Faulty ECU
	3	4	A	.80 ± .04	Faulty ECU
	4	5	A	.55 ± .04	Faulty ECU
	5	6	A	.33 ± .04	Faulty ECU
(ELECTRONIC) THROTTLE SENSOR TEST	1	1	B	1. Make note of “Closed Throttle” reading 2. Disconnect Yellow Sensor Module Wire from rectifier and touch to 12 volts. Reading should **climb** to initial “Normalized” (1.50) reading. 3. Draw air from sensor module tube. Reading should **drop** back to Test Meter (step #1 of Throttle Sensor Test) Reading. Example: Test Meter Reading - 1.26 Normalized Reading - 1.50 **(Note: See Illustration on Page 30)**	
AIR TEMPERATURE SENSOR TEST	1	1	C	Low 1.37 High 1.62	If meter reading is above 1.62, there is a faulty air temperature sensor or open sensor lead. If meter reading is below 1.37, there is a faulty air temperature sensor or shorted sensor lead.
COLD START ENRICHMENT TEST	1	6	A	Press cold start enrichment button. Meter reading should advance a minimum of three times the initial reading. Example: .34 x 3 = 1.02 	
IGNITION KILL TEST	1	1	A	Press Ignition Kill button. Meter reading should decrease 3 to 4 times, then fall to 0.01. Example: 1.50 0.48 0.35 0.01 	
PRESSURE TRANSDUCER TEST	1	1	A	Disconnect ECU transducer tube (a) from fitting on outboard. Draw air from tube. Meter reading should decrease as air is drawn from tube. If no number change, the ECU is faulty. 	

provided by http://www.crowleymarine.com