MERCURY MerCruiser

Service Bulletin

Bulletin No. 2006-06

Circulate to: ☐ Sales Manager ☐ Accounting ☑ Service Manager ☑ Technician ☑ Parts Manager

MerCruiser Engine Oil Capacities

Models Affected

Type	Model	Serial Number Range
Sterndrive	3.0L	OM300000 and above
	4.3L and 4.3L MPI	
	5.0L and 5.0L MPI	
	5.7L and 350 Mag	
	6.2L MPI	
	496 Mag and HO	OM025000 and above
Inboard and Ski	5.7L and 350 Mag	OM300000 and above
	6.2L	OM300000 and above
	Black Scorpion	OM391600 and above
	8.1L Horizon and HO	OM026000 and above

Situation

This bulletin supersedes previously published oil capacity information.

OIL CAPACITY CHART

Starting Year	Engine	Serial Number	Oil Capacity
2002	3.0L Sterndrive	0M300000 and above	3.8 liters (4 US qt.)
2002	4.3L and 4.3L MPI Sterndrive	0M300000 and above	3.8 liters (4 US qt.)
2002	5.0L and 5.0L MPI Sterndrive	0M300000 and above	4.25 liters (4.5 US qt.)
2002	5.7L and 350 Mag Sterndrive	0M300000 and above	4.25 liters (4.5 US qt.)
2002	6.2L MPI Sterndrive	0M300000 and above	4.25 liters (4.5 US qt.)
2001	496 Mag and HO Sterndrive	0M025000 and above	8.5 liters (9 US qt.)
2002	5.7L and 350 Mag Inboard and Ski	0M300000 and above	4.25 liters (4.5 US qt.)
2002	6.2L Inboard	0M300000 and above	4.25 liters (4.5 US qt.)
2003	Black Scorpion Ski	0M391600 and above	4.25 liters (4.5 US qt.)
2001	8.1 Horizon and HO Inboard	0M026000 and above	8.5 liters (9 US qt.)

THE INFORMATION IN THIS DOCUMENT IS CONFIDENTIAL AND PROTECTED BY COPYRIGHT AND IS THE PROPERTY OF MERCURY MARINE.

This document is provided for the sole and exclusive use of the original recipient as prescribed by Mercury Marine and may not be distributed or copied, digitally or otherwise, without the prior written consent of Mercury Marine.

provided by http://www.crowleymarine.com

IMPORTANT:

- **All capacities are approximate fluid measures and include the oil filter.**
- **Adjust oil levels as necessary to compensate for installation angles.**
- **Always use the dipstick to determine the exact quantity of oil required.**
- **Measure the final oil level with the boat at rest in the water.**
- **Do not overfill the crankcase.**

THE INFORMATION IN THIS DOCUMENT IS CONFIDENTIAL AND PROTECTED BY COPYRIGHT AND IS THE PROPERTY OF MERCURY MARINE.

This document is provided for the sole and exclusive use of the original recipient as prescribed by Mercury Marine and may not be distributed or copied, digitally or otherwise, without the prior written consent of Mercury Marine.

provided by http://www.crowleymarine.com